### MITZI ASSEMBLY

### SECTIONS

HEAD ASSEMBLY

CHEST ASSEMBLY

RIGHT ARM ASSEMBLY

LEFT ARM ASSEMBLY

LEG ASSEMBLY

AIR SUPPLY SYSTEM

COSTUMES & FIBERGLASS





#10

10.Head frame W/bearings M11440 MITZI HEAD ASSEMBLY EYES LEFT/RIGHT CYLINDER ASSEMBLY 11. Needle bearing only 28-005-010 36.Cylinder only 12. Bushing only 1000 37.Barb with O-ring **B56** 28-040-005 38.Clevis (front) 13. Bushing only (old style) 28-040-010 39.Clevis (rear) FB56-3 2400 40.Gasket (fiber style) (eye pivot) B56-4 ASSEMBLY HARDWARE EAR ASSEMBLY HARDWARE (attach cylinder 14.Ear lever w/bushing to eye linkage & rear mount) 15.Bushing only M11381 28-045-957 41.Cotter pin (ear lever) 16.FAS-PIN (ear lever B46-2 EYELID ASSEMBLY M13555 42.Eyelid to ear body) 28-055-172 17. Set screw 8-32 x 1/4" 28-090-302 43.FAS-PIN (eyelid cyl. 18.Ear cyl. rear mount 28-055-170 front mount) M07010 19. Hardware (ear cylinder 44.Shaft collar 28-070-015 (rear mount) rear mount to body) 28-090-341 45.Cyl. rear mount pin 8-32x1" cap screw 28-055-081 (7 1/2" dowel pin) 8-32 nut #8 flatwasher EYELID CYLINDER ASSEMBLY #8 lockwasher D31801-A 46.Cylinder only 47. Rebuild kit (Chicago EAR CYLINDER ASSEMBLY 28-012-035 cylinder) 20.Cylinder only 28-005-010 85-030-110 48. Fitting 21.Barb with O-ring 1000 49.Barb with O-ring 1000 28-040-005 22.Clevis (front) 2400 50.Gasket (fiber style) 28-040-010 23.Clevis (rear) 28-040-215 51.Jam nut 2400 28-040-015 24.Gasket (fiber style) 52.Clevis B46-2 53.Bushing (cyl. rear) ASSEMBLY HARDWARE HARDWARE (attach ear cylinder MOUTH ASSEMBLY to ear lever & rear mount) 54. Mouth lever w/bushing M11210 28-045-957 25.Cotter pin 55. Bushing only (mouth pivot) FB56-3 EYE ASSEMBLY 56.Bushing only M11250 B46-2 (mouth lever) 26.Eyeball 28-085-025 28-085-025 27.Bronze washer 57.Bronze washer 28-070-025 28.Shaft collar 58.Dowel pin 28-055-100 (mouth pivot) 59.Set screw 8-32 x 1/4" 28-090-302 EYE LINKAGE ASSEMBLY 29.Right eye act. lever M07100 60.FAS-PIN (cyl. front 28-055-170 30.Left eye act. lever M11270 and rear mount) 31.Mule bar(eye link.bar)M07180 61.Mouth cyl.rear mount M07230 28-070-010 62.Hardware (cyl. rear 32.Shaft collar 28-055-025 28-090-304 mount to head frame) 33.Dowel pin 34. Eye cyl. rear mount M07150 1/4-20x3/4" bolt 35.Hardware (eye cyl. rear 1/4-20 28-090-342 mount to head frame) flatwasher 1/4 10-32x3/4" cap screw lockwasher 1/4 nut 10-32 lockwasher #10 flatwasher

### MOUTH CYLINDER ASSEMBLY

63.Cylinder only 64.Rebuild kit (Chicago cylinder) 65.Fitting 66.Barb with O-ring 67.Gasket (fiber style) 68.Jam nut	D31801-A 28-012-035 85-030-110 1503 2400 28-040-215
69.Clevis 70.Bushing (cylinder rear)	28-040-015 B46-2

### E-HINGE ASSEMBLY

71.E-hinge with bearings 72.Needle bearing only 73.Dowel pin (E-hinge) 74.Retaining clip	M09442 B56 28-055-130 28-055-205
75.Load washer	28-085-125

### ASSEMBLY HARDWARE

76.Hardware (attach head to chest) 28-090-305
5/16-18 x 1" bolt
5/16 lockwasher


### HEAD UP/DOWN MOUNT ASSEMBLY

77. FAS-PIN (front cylinder mount)	28-055-178
78.Load washer	28-085-125
79.Set screw 8-32 x 1/4"	28-090-302
80.FAS-PIN (rear cylinder mount)	28-055-178

### HEAD UP/DOWN CYLINDER ASSEMBLY

81. Rebuild kit (brass cylinder)	28-010-210
82.Cylinder only	D31796-A
83. Rebuild kit (Chicago cylinder)	28-012-040
84.Fitting	85-030-110
85.Barb with O-ring	1000
86.Gasket (fiber style)	2400
87.Jam nut	28-040-225
88.Rod end	M19800
89.Bushing (cylinder only)	B58-3





	MITZI CHEST	ASSEMBLY	
10.Chest CHEST ASSEMBLY 11.Needle with bearings 12.Bush: Dearing only		HEAD LEFT/RIGHT CYLINDER	D ACCEMBLY
11. Needle bearing only 12. Bushing only (old	M17985	34.Cylinder only	28-015-037
12. Bushing only (old	B56	35.Cylinder rebuild kit	
la only (old		36. Fitting	85-030-110
13. Bushing only (old chest pivot)	FB56-3	37.Barb with O-ring	1000
and outh		38.Gasket (fiber style)	
14. Bushing only	B56-8	39. Bushing only (rear mnt	2400
only		block old style) *	B68-6
(lower neck)	B56-7	40.Spherical bearing	D00 0
IIDa		rear mount	28-015-280
15. Shaft with bearing	SEMBLY	41.Jam nut	28-040-227
- 2Cal IIId	,	42.Rod end	TRE-5
TO BOS ( APPET DECK)	M11490	4	1112 3
16.Bearing only 17.Bushing only	B45	LOWER NECK SHAFT ASS	SEMBLY
only		43. Shaft with bearing	<u> </u>
18.Shaft collar	B56-8		M11530
Collar		44. Bushing only	
19. Delrin (upper neck)	28-070-045		B56-8
	M06743	45.Bearing only	
	d	(new style)	B45
up/down cylinder) 21.Cap screws	M10020		
22. Set screws	28-045-970	BODY LEAN ASSEMB	<u>LY</u>
22. Set screw 8-32 x 1/4" 23. Actuation lever	28-090-302	46.Body lean lever	
radicion lever			M08680
(head left/right) 24.Set screw	M07420	47. Bushing only (body	
25. Roll pip (ald	28-090-306	lean actuation lever)	B68-4
25.Roll pin (old style)	28-060-045	48. Hardware (body lean ac	et.
26.FAS-PIN (act. lever) 27.Bronze washer	28-055-186	lever to chest frame)	28-090-307
28.Split shaft pin	28-085-025	5/16-18x2" bolt	
(with bushing)	20-055-125	5/16-18 nut	
29.Split shaft pin	28-055-125	5/16 flatwashe 5/16 lockwashe	
(with bearings)	28-055-200	5/16 lockwashe	er
29.5. Dowel pin	28-055-100		
23.3. Dower pin	20-055-100		
COLLAR PINS			
30.Collar pin(left/right			
arm raise rear mount)	28-050-060		
31.Collar pin (head left			
right cyl.rear mount)	28-050-013		
32. Shaft collar (head lef	t/		
right cyl.rear mount)	28-070-029		
33. Hardware (collar pin)	28-090-308		
3/8-24 nut			
3/8 lockwasher		* Replaces old-style h	block.
-/		-	

<sup>\*</sup> Replaces old-style block.

PELVIS PLATE ASSEMBLY M09605 49. Double C-hinge with bearing \* 50. Needle bearing only B56 M08350 51.Pelvis plate base \* 28-055-120 52. Dowel pin (C-hinge pin) 53. Retaining clip 28-055-205 28-085-125 54.Load washer 55.Body turn M10990 front mount plate only 56.Collar pin only 28-050-075 (body turn front mount) 57. Hardware (body turn to 28-090-343 pelvis plate) 5/16-24x1 1/2" bolt 5/16-24 nut 5/16 flatwasher 5/16 lockwasher 58. Hardware (attach pelvis plate to leg assembly) 28-090-344 5/16-18x1" bolt 5/16 lockwasher 5/16 flatwasher 59. Hardware (attach double C-hinge to pelvis plate base) 28-045-969 Tapered flat head cap screw \*


\* If you have a welded pelvis plate then you must order the following parts to get an entire pelvis plate assembly:

1 - M09605

1 - M08350

4 - 28-045-969

Individual parts may be ordered if you have an assembled plate.



## MITZI RIGHT ARM ASSEMBLY

	_	TILLET KIGHT I		
10.Small K-hinge		MITZI UPPER RIGHT ARM ASSEMBLY		
			27. Upper right arm	
]	with bearings only	M18060	with bearings	M12035
	only only	1110000	28. Needle bearing only	B56
	(old style) 12.Needle bearing only 13.Collar pin (cylinder)	FB56-3	29. Hardware (attach uppe	er
	13 Colle bearing only	B56	arm to shoulder)	28-090-345
	13.Collar pin (cylinder rear mount pin)	230	1/4-20x1 1/4" bolt	
	rear mount pin)	28-050-025	1/4-20 nut	
	14.Collar pin	20 000 020		asher
		28-050-015	1/4 locky	asher
	awate (collar nin)	28-090-308		
			MITZI LOWER RIGHT ARM	ASSEMBLY
	16 shaft lockwasher		30.Lower right arm	W2 0.0E.0
	- Sudit Collar (cylinde	r	with bearings	M12050
		28-070-029	31.Lower arm pivot	EDE 6-3
	27. Shoulder shaft block		bushing (old)	FB56-3
	With hughing	M09870	<pre>32.Lower arm lever     bushing</pre>	28-032-035
	18. Bushing only		33.Needle bearing only	20 032 000
	(shoulder shaft block	c) FB810-4	(arm pivot)	B56
	19. Hardware (shoulder sha	ift	(dim pivoc)	
	block to K-hinge)	28-090-310	E-HINGE ASSEME	LY
	1/4-20x2 1/2" bolt		34.E-hinge w/bearings	M09442
1	1/4-20 nut 1/4 flats	washer	35. Needle bearing only	B56
		washer	36.E-hinge pin	
	20.Shoulder shaft	Washer	(dowel pin)	28-055-130
	(small shoulder)	M11800	37.Load washer	28-085-125
	21.Actuation lever		38.Retaining clip	28-055-205
	(small shoulder)	M07380	THE CULTURED OF	CCEMPIV
	22.Set screw 8-32 x 1/4	28-090-302	SHOULDER CYLINDER A	28-015-040
	23. Hardware		39.Cylinder only 40.Rebuild kit	28-015-016
	(small shoulder	) 28-045-972	41.Fitting	85-030-110
	Cap screw		42.Barb with O-ring	
	#10 lockwasher		43.Gasket (fiber style)	2400
	24.Dowel pin	\ 00 0FF_007	44.Jam nut	28-040-227
	(cyl. front mount	) 28-055-067	45.Rod end	TRE-5
	25.Roll pin	V 20-060-045	46. Bushing for	
	25.Roll pin (to pin act. lever	7 28-000 043	rear mount block	B68-4
			47.Spherical bearing	
	ASSEMBLY HARDW	rht.	for rear moun	nt 28-015-280
	26.Hardware (attach rig	28-090-309		
	5/16-18x1 1/2" bol		ASSEMBLY HARD	MAKE
		kwasher	HARDWARE (attach upper	to lower arm)
	5/16			28-055-180
			48. Dowel pin	28-055-205
			49.Retaining clip 50.Load washer	28-085-125
			O. LOAU WASHEL	



# RIGHT ELBOW CYLINDER ASSEMBLY

51.Rebuild kit (brass	
52.Cylinder only	28-010-210
53. Rebuild kit (Chicago	D31796-A
54. Fitting cylinder)	28-012-040
54.Ficting	85-030-110
55. Barb with O-ring	1001
56. Gasket (fiber style)	2400
5/.Jam nut	28-040-225
58.Clevis	28-040-025
59. Bushing (cyl. rear)	B59-3

# HARDWARE (attach cylinder to upper and lower arm)

60.FAS-PIN (upper arm) 61.Set screw	28-055-176
8-32 x 1/4" long	28-090-302
62.FAS-PIN (lower arm)	28-055-178

# RIGHT ARM RAISE CYLINDER ASSEMBLY

only	D31794-A
63.Cylinder only 64.Rebuild kit (Chicago cylinder)	28-012-040
65 Fitting	85-030-110 1001
66.Barb with O-ring 67.Gasket (fiber style)	2400 28-040-225
68.Jam nut	M19810
69.Rod end 70.Bushing (cyl. rear)	B68-3

# ASSEMBLY HARDWARE

HARDWARE (attach cylinder to arm and chest) 71.Shaft collar 28-070-029

### DUCT HOSE ASSEMBLY

72.Duct hose (arm cover) ADH 1502
73.Hardware (attach duct hose to arm) 28-057-044
Threaded rod
1/4-20 x 3 1/2"
74.Hardware (attach duct hose to arm) 28-090-329
1/4-20 nut
1/4 flatwasher
1/4 lockwasher

# MITZI LEFT ARM ASSEMBLY

	at LEFT ARM MODEL	
10.Small K-bings UPPER LEFT ARM ASSEMBLY		
-, *ITHOE	ar unner left arm	
11. Bushing only	with bearings	M12033
and outh	as Needle bearing only	B56
12.Needle (old K-hinge) FB56	-3 29.Hardware (attach	211
12.Needle bearing only	upper arm to shoulder).	28-090-311
13.Collar (new K-hinge) B56	1/4-20x1 1/2" bolt	
13. Collar pin (aulina)	1/4-20 nut	
rear mount pin) 28-0	1/4 flatwa	sher
14. Collar pin (Arm	50-025 1/4 lockwa	sher
raise from (Arm	-/ -	
raise front mount) 28-0	50-015 LOWER LEFT ARM ASSE	MBLY
15. Hardware (collar pin) 28-0	30.Lower left arm	
5/5 24 Hut	with bearings	M12050
16 3/8 lockwasher	#	
10.Shaft collar (cylinder	31.Lower arm pivot bushing (old)	FB56-3
rear mount hin) 28-0	70-029	1 550 0
17. Shoulder shaft block		28-032-035
with bushing M098		B56
18. Bushing only	33.Needle bearing only	D30
(shoulder shaft block) FB81	10-4	
19. Hardware (shoulder shaft		M00442
block to K-hinges) 28-0	090-365 34.E-hinge with bearings	MU9442
1/4-20x2" bolt		20 055-130
1/4-20 nut	36.E-hinge pin(dowel pin)	28-035-130
- 11	37. Load washer	28-065-125
1/4 flatwasher	38.Retaining clip	28-055-205
1/4 lockwasher		
20.Shoulder shaft (small shoulder) M11	SHOULDER CYLINDER AS	SEMBLY
(SMAIL DISALES)	39 CVIInder Only	28-015-040
21.Actuation lever	to pobuild kit	28-015-214
(small shoulder) M07	41. Fitting	85-030-110
22.Set screw 8-32 x 1/4" 28-	A2 Barb with O-ring	1000
23.Hardware	(fiber style)	2400
(small shoulder) 28-	045-972 43.Gasket (liber style) 44.Jam nut	28-040-227
Cap screw	45.Rod end	TRE-5
#10 lockwasher	46.Bushing for	
cylinder	many mount	B68-4
front mount) 28-		
•	47.Spherical bearing for rear mount	28-015-280
25.Roll pin (to pin act. lever) 28-	060-045 IOI Teal mount	
(to pin acc. icvoz)	- CORNEL WARDING	DF
TOTAL WADDWARE	ASSEMBLY HARDWA	28-055-180
ASSEMBLY HARDWARE	48.Dowel pin	28-055-205
26. Hardware (attach	000-309 49.Retaining Clip	28-035-205
	50.Load washer	28-085-125
- (a c 10 v1 1 / ) " DUIC		
5/16 10ckwash	E1	
-/-		



# LEFT ELBOW CYLINDER ASSEMBLY

51.Rebuild kit (brass	
52 Cylinder)	28-010-210
52.Cylinder only	D31796-A
53. Rebuild kit (Chicago	
cylinder)	28-012-040
54.Fitting	85-030-110
55.Barb with O-ring	1001
56. Gasket (fiber style)	2400
57.Jam nut	
	28-040-225
58.Clevis	28-040-025
59. Bushing (cyl. rear)	B58-3

### ASSEMBLY HARDWARE

HARDWARE (attach cylinder to upper and lower arm) 60.FAS-PIN (upper arm mount) 28-055-176 61.Set screw 8-32 x 1/4" 28-090-302 62.FAS-PIN (lower arm mount) 28-055-178

# LEFT ARM RAISE CYLINDER ASSEMBLY

LEFT ARM 200	D31794-A
63.Cylinder only 64.Rebuild kit (Chicago cylinder)	28-012-040 85-030-110
65.Fitting 66.Barb with O-ring 67.Gasket (fiber style) 68.Jam nut	1001 2400 28-040-225 M19810
	B68-3

# ASSEMBLY HARDWARE

HARDWARE (attach arm raise cylinder to arm and chest) 71.Shaft collar 28-070-030

### DUCT HOSE ASSEMBLY

72. Duct hose (arm cover) ADH 1502

73. Hardware (attach duct

hose to arm) 28-057-044

Threaded rod

 $1/4-20 \times 3 1/2$ "
74. Hardware (attach duct


hose to arm) 28-090-329

1/4-20 nut

1/4 flatwasher

1/4 lockwasher





MITZI LEG ASSEMBLY						
10 Mitzi legs 11. Spindle (body	M18020		SEMBLY HARDWAF ttach cylinder to leg			
12.Clamping collar	M11620	30.Shaft co	llar	28-070-029		
13 Pilling collar	28-070-074	31.Alignmen	t rod (body			
13.Pillow block bearing 14.Hardware (pillow	28-025-410	tw	ist cylinder)	M07790		
	20 025 410	32.Hardware				
	28-090-308	1	egs to floor)	28-090-323		
2/0-44X1 1/2# halt	20-090-300		x1 1/2" bolt			
nut		3/8-16				
3/0	asher	3/8	flatwa	asher		
- · DOM	M19827	3/8	lockwa	asher		
	1117027	,				
1/4-20 2/4"	28-090-302	BODY LE	AN CYLINDER AS	SSEMBLY		
17. Body turn mount	20 030 302	33.Rebuild	kit (brass			
Stool wlata	M07740		cylinder)	28-010-265		
to. Collar nin only	28-050-070	34.Cylinder	only	D31802-A		
- Mardware (attach		35.Rebuild	kit (Chicago			
collar pin to mount)	28-090-308		cylinder)	28-012-050		
3/8-24 nut		36.Fitting		85-020-031		
3/8 lockwasher		37.Jam nut		28-040-245		
		38.Clevis		28-040-040		
ASSEMBLY HARDWA	RE		(cyl. rear)			
20. Hardware (attach body	,	(Chica	igo only)	B810-4		
turn mount to legs)	28-090-349					
5/16-18x1 1/2" bolt	:		SEMBLY HARDWA			
5/16-18 nut		HARDWARE (a	attach cylinde			
5/16 loc	washer			t and legs)		
		40.FAS-PIN	(front mount)	28-055-182		
BODY TWIST CYLINDER		41.FAS-PIN	(rear mount)	28-055-184		
21.Cylinder only	28-015-070		1			
22.Rebuild kit	28-015-210					
23.Fitting	85-030-110					
24.Barb with O-ring	1000					
25.Gasket (fiber style)	2400					
26.Jam nut	28-040-220					

TRE-5

(between cyl.) M07270

29.Hardware (body twist cylinder) 28-090-317 10-24x5" screw

flatwasher

lockwasher

nut


27.Rod end

28.Alignment bar

10-24

#10

#10



# 16

#### MITZI AIR SUPPLY SYSTEM

	MITZI AIR	SUPPLY SYSTEM			
10. Hose 1/16" *					
11 TOSE 1/16" +	ASSEMBLY	VALVE BANK ASSEMBLY			
13 nose (1/8")	80-005-007		-080-970		
11. Hose 1/16" * 12. Hose (1/8") .125 *	80-005-010		000 3.0		
12.Hose (1/8") .125 *	80-015-015	bracket to valve bank) 28-	-090-318		
		10-32x2 1/2" bolt	-030-310		
13. 24-hole plate	SSEMBT.V	10-32 1/2 Bolt			
nim, Page					
plumbing harness s 14. 24-hole plate valve bank	ide Misono				
Value plate	1113000				
FITTINGS STIR SIDE	M12950	FITTINGS (barb size depends			
15.Barb 1/16" x 10-32	M12930	on val	lve use)		
16 Pari 1/16" x 10-32	1000	31.Barb .125 x 1/8" MPT 85-	-010-012		
16.Barb .125 x 10-32 17.Barb .170 x 10-32	1000	32.Barb .170 x 1/8" MPT 85-	-010-014		
17.Barb .170 x 10-32 18.Gasket (fiber	1001	33.Plug 1/8"socket head 85-	-060-010		
18.Gasket (fiber styl	1503	34. Hose (valve bank to			
19.0-ring(between pla 20.Hardware (attach	e) 2400	exhaust port manifold)			
20. Hardware (attach	ces) 28-045-955	(1/8") .125 clippard* 80-	005-010		
quick release		35. Valve bank fitting			
		3/8" push-lock			
1/4-20x1 1/2" bo	28-090-311		010-044		
1/4-20 nu	10	36. Hose (valve bank to muf-			
7 / 4		<pre>fler &amp; intake T-fitting)</pre>			
1/4	atwasher	3/8" push-lock * 80-	020-029		
, ,	ckwasher	37. Exhaust pilot pressure			
FLOW COMMON	0.07117	manifold (12-port) 85-	045-020		
FLOW CONTROL A	SSEMBLY	FITTING (exhaust pilot			
FITTINGS (bash -i	FC-32	pressure ma	pressure manifold)		
FITTINGS (barb size d	epends on	38.Barb .125 x 10-32 100	1		
22. Barb 1/6" 10 22	w control use)		045-030		
22. Barb 1/6" x 10-32	1000	40.Gasket (fiber style) 240	0		
23.Barb .125 x 10-32	1001	41.Barb 1/4" x 1/8" MPT 85-	010-015		
24.Barb .170 x 10-32 25.Gasket (fiber styl	1503	42.Hose (exhaust pilot			
HOSE (mick release)	e) 2400	pressure manifold			
HOSE (quick release t	o valve bank)	to muffler)			
26.Hose 1/16" clippar	d * 80-005-007		-020-015		
27. Hose .125 clippard	* 80-005-010	43. Valve (single valve) 28-	-080-110		
28.Hose .170 purple *	80-015-015	44.Lock ring 28-	-080-940		
		45. Valve repair			
		Main spool kit 28-	-080-920		
		46.Seal repair kit 28-	-080-910		
		47. Gasket (between valves) 28-	-080-950		
		48.0-ring gasket 28-	-080-952		
		40 411 43	-080-955		
		50. End plate set with	000-935		
	***		-080-960		
		1 = 20	200		



<sup>\*</sup> Order hose by the foot

# J

# MITZI COSTUME & FIBERGLASS

			CODIUME	a ribbrounds		
	1.	HEAD ASSEMBLY		HEAD		
5	2.	tar (each)	AE35 8401	1. Skull - fiberglass AE56 019		
	4	Mask complete * a. Tongue only Eyelashes	AE33 52007 AE31 9401	HARDWARE (attach skull		
	•	Eyelashes	AF31 6612 21-050-060	2. Threaded rod 1/4-20 x 2 1/8" 28-057-026		
		NECV ACCE		3. Threaded rod  1/4-20 x 2 3/8" 28-057-027		
	1.	NECK ASSEMBLY Dickey		4. Hardware (att. skull to head frame) 28-090-329		
	۷,	Leather neck guard	AE34 4818 AE36 48002	1/4-20 nut 1/4 flatwasher 1/4 lockwasher		
	1	CHEST ASSEMBLY	<u> </u>	DIGMATA ANALYSIS		
	4.	Sweater Latex breast plate Leather (backguard)	AE33 2504 AE34 4208 AE40 5905	PIGTAIL MOUNT  5. Pigtail mount M19390  6. Hardware (attach pig-		
4)		SHOULDER ASSEMB		tail mount to skull) 28-090-320 1/4-20x1" bolt 1/4-20 nut		
1.	1.	Leather (right shoulder guard) AE37 1004		1/4 flatwasher 1/4 lockwasher		
	2.	Leather (left shoulder guard)		BODY		
		UAND ACCOMPLY		7. Body - fiberglass		
	1	HAND ASSEMBLY Right hand		(right side) AE57 020 8. Body - fiberglass (left side) AE58 021		
		with pom-pom * Left hand	AE32 9202	HARDWARE (attach body to chest) 9. Threaded rod		
		with pom-pom * Pom-pom only (each)		5/16-18 x 5" 28-057-055 10. Hardware (attach		
				body to chest) 28-090-330 5/16-18 nut		
		LEG ASSEMBLY	1E22 2402	5/16 flatwasher 5/16 lockwasher 11. Body mount tabs		
	2.	Left fur leg *	AE33 2403 AE45 8702 AE45 8802	(body button) M13340 12. Hardware (attach body		
	4.	Right shoe	AE34 4619 AE34 4419	halves together) 28-090-304 1/4-20x3/4" bolt 1/4-20 nut		
7)		* IF STORE OPEN PRIOR 1/1/82, SPECIFY OLD- FUR WHEN ORDERING.	TO STYLE	1/4 flatwasher 1/4 lockwasher		